



## EZ Spread™ Spreader Control

### Product Summary

- A ground speed oriented or ground speed triggered spreader control;
- Available in two or three channel models (EZ 2 or EZ 3);
- Manual proportional control for auger(or conveyor), spinner and auxiliary (pre-wet, cross conveyor) channels;
- Adjustable, min/max trim-able settings from 0-10;
- Back lit control panel;
- Programmable trim settings;

### Product Application

- Entry level electric controller for spreading granular material with or without pre wet;

### 2 or Proportional Application Channel Options

- Independent control of 2 or 3 proportional channels;
- Usually configured for auger/conveyor, spinner and either cross auger or pre-wet;

### Ground Speed Options

- Ground Speed Triggered (GST): on with truck motion, off with truck motion;
- Ground Speed Oriented (GSO): on with truck, automatically adjusts output to compensate for truck speed, off when truck stops;

### Hydraulic Trimming

- Configuration mode for hydraulic trimming without manual trim pots;

### Blast and Pass

- Programmable Blast Included (on/off, timed);
- Remote Blast and Remote Pass accessible using Cirus plow controls;

### Output Signal

- Multiple Frequency settings for ease of valve compatibility;

### Power Safety

- **Power Safe™** signals prevents random grounds powering any hydraulics system attached (auger, spinner, conveyor, etc);

### System Mounting

- Flip-Arm or Mongoose arm Console;
- Seat mount or pedestal mount;
- Stand Alone;

### Black Tip Combination

- Integrates with Black Tip for one ton plow control applications

### Operating Temperature Range

- Minimum: -20 degrees Centigrade
- Maximum: 70 degrees Centigrade

### Power Requirements

- Minimum: 11 Volts DC
- Maximum: 15 Volts DC
- Maximum: 10 Amps
- Internal fuses rated at 10 Amps